SI			A mount nor
		Unit of	Amount per
No	Description of Item (2)	Measurement (3)	line item
			PEMA KHANGSAR MOTOR WORKS
1	Battery terminal end	Each	100
2	A/C filter	per piece	650
3	Alternator Assy	Each	10500
4	Alternator carbon	Each	250
	bush		
5	Alternator cut out	Each	800
6	Anabond paste (Big)	Each	125
7	Anabond paste (Small)	Each	65
8	Back bumper	Each	1250
9	Back light Assy (Left)	Each	475
10	Back light Assy (Right)	Each	475
11	Battery cable +ive	Each	250
12	Battery cable -ive	Each	250
13	Bendix pinion	Each	850
14	Black tape	per piece	25
15	Brake light switch	Each	150
16	Bulb 1141	Each	20
17	Bulb 67	Each	15
18	bush stabilzer	per piece	100
19	Carbon bush 12 v	Each	100
20	Carbon holder	Each	750
21	Carbon rocker 12v	Each	750
22	cloth piece	per meter	10
23	collant	per ltre	295
24	dash board polish	per piece	250
25	Dial wrench (6-32mm)	Set	1050
26	distilled water	per ltre	25
27	Dust guard back and	Set	1250
	front		
28	Dynamo bearing	Each	250
29	Dynamo rocker	Each	250
30	Electric horn 2v	Each	450
31	foot mat	Set	2500
32	Front bumper	Each	3250
33	fuel and water	per piece	200
	separator		
34	fuel pipe	per piece	350
35	Fuse 10 Amp	Each	10
36	Fuse 15 Amp	Each	10
37	Fuse 20 Amp	Each	10

38	Fuse 25 Amp	Each	15
39	Fuse 30 Amp	Each	15
40	Fuse 5 Amp	Each	10
41	Glow plug	Each	25
	Grease		
42		per kg	285
43	Grease gun	Each	1050
44	Head light Assy (Left)	Each	2200
45	Head light Assy (Right)	Each	2200
46	Head light bulb	Each	150
45	(Halogen)	7. 1	
47	Horn high	Each	650
48	Horn low	Each	450
49	Horn relay	Each	200
50	horn switch	per piece	150
51	Hour meter	Each	10
52	Ignition switch	Each	975
53	LT wire 5mm	Each	25
54	LT wire 6mm	Each	25
55	LT wire 8mm	Each	50
56	Mobil (15w40)	per ltre	425
57	nozzle pipe	per piece	150
58	Plastic lock	Each	10
59	Plastic tape	Each	20
60	PVC tape	Each	20
61	Rain guard	Set	1250
62	Rear tail board railing	Each	2500
63	Rectifier	Each	750
64	Red paper	Each	25
65	Relay 2 pin 12v	Each	100
66	Relay 3 pin 12v	Each	100
67	Relay 4 pin 12v	Each	200
68	Relay 5 pin 12v	Each	200
69	Rotor coil	Each	750
70	seat cover	Set	6500
71	Self Armerture 12v	Each	1850
72	Self bush 12V	Each	50
73	Self carbon 12V	Each	200
74	Self field coil 12v	Each	450
75	Self housing	Each	1250
76	Self top cover	Each	200
77	Solonoid switch 12v	Each	1250
78	Speedo meter Assy	Each	1850
79	Speedo meter cable	Each	450
80	Speedo meter pinion	Each	150
81	Starter coil	Each	950
_			

82	Starter relay 12v	Each	250
83	steering cover	per piece	550
84	Threading tape	Each	20
85	vacuum nozzle pipe	per piece	5
86	vehicle no. plate	per piece	500
87	wheel Drum	Each	3200
88	Wiper blade Assy	Each	250
89	Wiper motor	Each	2650
90	Wiring clip	Each	5
91	Bearing 6202	Each	250
92	Bearing 6302	Each	250
93	Benjo washer	Each	5
	-		
94	Cam shaft	Each	2800
95	Cam shaft bush	Each	450
96	Cam shaft gear	Each	250
97	Connecting bearing	Each	1250
98	Connecting bush	Each	275
99	Coonecting rod	Each	2500
	Crank shaft	Each	12500
101	Crank shaft oil seal	Each	950
102	Diesel filter	Each	200
103	Drain plug	Each	75
104	Element Assy, Fuel	Each	1850
105	Element sub assy, Air	Each	550
106	Engine head gasket	Each	1200
107	Engine mounting	Each	350
108	Engine pacing	Each	1750
109	Engine ring	Each	2200
110	Fan belt	Each	350
111	Feed pump Assy	Each	1450
112	Fuel filter	Each	200
113	Fuel injection	Each	250
	overflow pipe		
114	Fuel injector nozzel	Each	1150
115	Fuel injector pipe	Each	250
116	Fuel pump Assy	Each	48000
117	Fuel pump washer	Each	10
118	Gas kit	Each	100
119	Hydraulic jack (Heavy	Each	2800
	Duty)		
120	Hydraulic jack (Light	Each	2500
	Duty)		
121	Hydraulic jack oil seal	Each	250
	(Set of 12 pcs)		
122	Inner door lock (R)	Each	200

123 Inner door lock(L) 124 Jack lever Each 125 Main bearing Each 126 Mobil 127 Mobile filter Each 128 Open end wrench set (6-32mm) 129 Piston Each 130 Piston ring Each 131 Rocker Arm Each 132 Rocker shaft Each 133 Silencer box Each 134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Timing cover oil seal Each Each	250 1450 425 275 1050 2200 2850 250 2500 2500 2500 3800 200 175 250 150 250
126 Mobil per ltre 127 Mobile filter Each 128 Open end wrench set (6-32mm) 129 Piston Each 130 Piston ring Each 131 Rocker Arm Each 132 Rocker shaft Each 133 Silencer box Each 134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal 139 Timing belt Each	1450 425 275 1050 2200 2850 250 250 2500 2500 3800 200 175 250 150
126 Mobil per ltre 127 Mobile filter Each 128 Open end wrench set (6-32mm) 129 Piston Each 130 Piston ring Each 131 Rocker Arm Each 132 Rocker shaft Each 133 Silencer box Each 134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal 139 Timing belt Each	275 1050 2200 2850 250 250 2500 2500 2500 3800 200 175 250
127 Mobile filter Each 128 Open end wrench set (6-32mm) Set 129 Piston Each 130 Piston ring Each 131 Rocker Arm Each 132 Rocker shaft Each 133 Silencer box Each 134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	275 1050 2200 2850 250 250 2500 2500 2500 3800 200 175 250
128 Open end wrench set (6-32mm) Set 129 Piston Each 130 Piston ring Each 131 Rocker Arm Each 132 Rocker shaft Each 133 Silencer box Each 134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	2200 2850 250 250 2500 2500 3800 200 175 250
(6-32mm) Each 129 Piston Each 130 Piston ring Each 131 Rocker Arm Each 132 Rocker shaft Each 133 Silencer box Each 134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	2850 250 250 2500 2500 3800 200 175 250
130 Piston ring Each 131 Rocker Arm Each 132 Rocker shaft Each 133 Silencer box Each 134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	2850 250 250 2500 2500 3800 200 175 250
131Rocker ArmEach132Rocker shaftEach133Silencer boxEach134Silencer pipeEach135Socket (6mm-32mm)Set136Tappid cover packingEach137Thrust washerEach138Timing cover oil sealEach139Timing beltEach	250 250 2500 2500 3800 200 175 250
131Rocker ArmEach132Rocker shaftEach133Silencer boxEach134Silencer pipeEach135Socket (6mm-32mm)Set136Tappid cover packingEach137Thrust washerEach138Timing cover oil sealEach139Timing beltEach	250 2500 2500 3800 200 175 250
133 Silencer box Each 134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	2500 2500 3800 200 175 250
134 Silencer pipe Each 135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	2500 3800 200 175 250
135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	3800 200 175 250 150
135 Socket (6mm-32mm) Set 136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	3800 200 175 250 150
136 Tappid cover packing Each 137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	175 250 150
137 Thrust washer Each 138 Timing cover oil seal Each 139 Timing belt Each	250 150
139 Timing belt Each	150
139 Timing belt Each	150
	250
I TO I THINK SO YOU	
141 Timing cover gear Each	675
142 Valve guide Each	100
143 Valve key Each	10
144 Valve seal Each	50
145 Valve spring Each	10
146 Valve washer Each	10
147 Wheel wrench Each	750
148 Wiper Arm Each	450
149 Wiper blade Each	250
150 Wiper motor Assy Each	2850
151 Axel lock Each	100
152 Axel shaft Each	3850
153 Axel shaft oil seal Each	150
154 Axel spacer Each	175
155 Back gear bearing Each	250
156 ball joint per piece	850
157 C.V joint per piece	2000
158 Center bearing Each	1650
159 Clutch cylinder (lower) Each	1050
160 Clutch cylinder Each	1650
(Upper)	
161 Clutch cylinder Assy Each	1050
162 Clutch cylinder kit Each	250
163 Clutch kit Each	250
164 Clutch kit box Each	250
165 Clutch plate (Fan Each	200

	Type)		
166	Clutch plate (Round	Each	4850
	Type)		
167	Clutch relese bearing	Each	1250
168	Clutch rod	Each	100
169	Cross bearing	Each	650
170	Cross holder	Each	1150
171	Cross propeller shaft	Each	650
	Crown tail assy	Each	6800
	Fly wheel	Each	1850
	Fly wheel ring	Each	850
	Front hub bearing	Each	850
	inner	Lucii	030
176	Front hub bearing	Each	750
	outer		
177	Gear box mounting	Each	450
178	Gear box oil seal	Each	150
179	Gear box packing	Each	100
180	Gear counter	Each	2200
181	Gear oil	per ltre	325
182	Gear pinion	Each	2200
183	Gear pinion shaft	Each	100
184	Hubs bearing	per piece	750
185	Hubs checknut	Each	100
186	Hubs checknut lock	Each	75
187	Master cylinder	Each	3200
188	Master cylinder kit	Each	650
189	Pilot bearing	Each	450
190	Pressure plate	Each	3850
191	Propeller shaft	Each	4500
192	Propeller shaft bolt	Each	35
193	Rear hub bearing inner	Each	875
194	Rear hub bearing	Each	750
	outer		
195	Relese bearing fork	Each	350
196	Relese bearing lock	Each	100
197	Tail pinion bearing	Each	750
	(inner)		
198	Tail pinion bearing	Each	750
	(Outer)		
199	Tail pinion chechnut	Each	100
	washer		
200	Tail pinion checknut	Each	150
201	Tail Pinion oil seal	piece	450
202	Top shaft bearing	Each	875

203	Wheel bearing inner	Each	775
	(Front)		
204	Wheel bearing inner	Each	875
	(Rear)		
205	Wheel bearing oil seal	Each	100
	inner (Front)		
206	Wheel bearing oil seal	Each	150
200	inner (Rear)		
207	Wheel bearing outer	Each	700
207	wheel bearing outer	Each	700
	(Front)		
208	Wheel bearing outer	Each	750
	m)		
	(Rear)		
	Wheel cylinder	Each	850
	Wheel cylinder bucket	Each	200
211	Wheel nut	Each	100
212	Accelerator cable	Each	325
213	Brake Booster Assy	Each	8500
214	Brake Booster kit	Each	550
215	Brake cam	Each	10
216	Brake cam Arm	Each	5
217	Brake cam Arm lock	Each	5
	Brake cam bush	Each	5
	brake disc		3200
		Each	
220	Brake flexible pipe	Each	350
	(Front)		
	Brake fluid dot3	Each	125
222	brake light bulb	per piece	20
223	Brake lining	Each	750
224	Brake oil	per litres	125
225	Brake pad	Each	1000
226	Brake pipe (Rear)	Each	350
227	Brake servo	Each	10
228	Brake shoe	Each	1150
	Brake shoe lock with	Each	100
	spring		
220	Break bucket	Each	100
231	Break lining back and	Each	750
	front	-	
	Break shoe	Each	675
233	Controlling cylinder	Each	10
	Assy		
234	Controlling pipe	Each	10
			10
233	Controlling switch	Each	10
	Assy		

236	Dual brake valve Assy	Each	10
	Hand brake cable	Each	650
	Oil seal	Each	100
	Spring 2nd leaf (R)	Each	1150
	Spring 2nd leaf (F)	Each	750
241		Each	850
	Spring 3rd leaf (F)	Each	650
	Spring 4th leaf ®	Each	750
	Spring 4th leaf (F)	Each	500
	Spring 5th leaf ®	Each	500
	Spring 5th leaf (F)	Each	400
	Spring 6th leaf ®	Each	350
	Spring 6th leaf (F)	Each	300
	Centre bolt	Each	50
	Cycle pin	Each	175
	Helper leaf Spring	Each	750
	Main leaf spring (R)	Each	1150
	Main leaf spring (F)	Each	850
	Shock absorber	Each	1200
	Shocker nut bolt	Each	50
		Each	250
230	Spring buffer	Each	230
	mounting		
257	Spring bush	Each	100
258	Spring clamp	Each	150
259	Spring cycle pin	Each	150
260	Spring hanger	Each	650
261	Spring pin	Each	150
262	Spring shackle	Each	550
263	U bolt	Each	250
264	U bolt nut	Each	45
265	U bolt plate	Each	295
266	Air filter	Each	450
267	Air filter hose pipe	Each	250
268	Coolant	per litres	245
269	Exhaust manifold	Each	1950
270	Hose pipe clamp	Each	50
271	Hydraulic filter	Each	10
272	Hydraulic oil	per ltre	200
273	Hydraulic pipe	Each	10
274	Intake manifold	Each	1200
275	Radiator assy	Each	4850
276	Radiator cap	Each	200
277	radiator hose pipe	Each	300
	(Lower)		
	(Lower)		

278	Radiator hose pipe	Each	300
276	Radiator nose pipe	Each	300
	(Upper)		
	Vacuum pipe	Each	10
	Arm bushing lower big	Each	450
281	Arm bushing lower	Each	450
	small		
282	Power steering box	Each	18500
	Assy		
283	Steering adjuster bolt	Each	100
200		Ewen.	
	Assy		
	Steering box oil seal	Each	100
285	Steering column	Each	250
	(Inner)		
286	Steering column	Each	250
	(Outer)		
287	Steering cross	Each	750
	Steering cross bearing	Each	750
	Tie rod end	Each	595
290	Back glass	Each	2500
291	Front Windshield glass	Each	4800
292	Looking glass (R)	Each	375
293	Looking glass (L)	Each	375
294	Window glass	Each	1000
295	Power steering	Each	250
	bearing		
296	Power steering oil	per litres	330
	Power steering pipe	Each	200
	Head light assembly	Each	2200
299	Head light bulb	Each	150
	Head light cover	Each	250
301	Indicator light	Each	275
302	Side light	Each	10
303	Gear Box Opening and	each	3500
	fitting charges		
304	Spring opening and	each	350
200	fitting charges		
	A/c filter changing	per piece	100
306	Accelerator cable	Each	100
	changing		
307	Air compressor	Each	10
	leakage repairing		
	iouxuge repairing		

308	Air Element changing	Each	100
	Air filter changing	Each	100
	Air filter hose pipe	Each	100
	changing		
	Air filter servicing	Each	100
312	Air tank opening &	Each	10
	refitting		
313	Air unloader opening & new service kit	Each	10
	fitting		
314	Alternator cut out	Each	450
	changing		
315	Alternator overhauling	Each	450
	Arm bush change	Each	450
217	charges	F1-	100
317	Back light assy	Each	100
	changing		
318	Back light bulb	Each	100
	changing		
319	ball joint changing	per piece	450
	Battery box new	Each	350
	·		
	making		
	Battery cable changing	Each	100
	Battery change	Each	50
323	Battery terminal	Each	50
	changing		
324	Bendix pinion	Each	150
	repairing & replacing		
325	Brake adjuster	Each	10
	opening & refitting		
326	Brake cam bush	Each	10
	opening & fitting		
327	Brake diafam opening & new service kit	Each	10
	changing		
328	Brake dise cutting	Each	650
329	brake disc changing	Each	350
330	Brake drum cutting	Each	500
331	Brake dual valve kit	Each	10
	changing		
332	Brake flexible pipe	Each	100
	changing Brake linning changing	Each	250
222			

334	brake pipe bleasting	each	150
	Brake pipe changing	Each	150
	Brake pipe leakage	Each	150
330	Drake pipe leakage	Lucii	150
	repairing		
337	Brake servo Changing	Each	20
338	Brake servo repairing	Each	20
	& servicing		
339	Brake Shoe Changing	Each	350
	Brass blezzing	Each	150
	Carbon soldering	Each	100
	Center bearing	Each	350
	-		
2.42	changing		2400
	Clutch plate changing	Each	2500
344	Clutch release bearing	Each	500
245	changing	F 1	450
	Coil Spring changing	Each	450
	collant change	Each	150
347	Controlling	Each	10
	overhauling		
348	Controlling pipe	Each	10
	changing		
349	Cross bearing	Each	450
	-		
	changing		
	Cross bearing greasing	Each	350
	Cross Coupling cutting by lath machine	each	550
352	Cross holder cutting	Each	550
	and welding		
353	Crown Overhauling	Each	2000
354	CV joint changing	per piece	250
355	Cycle pin changing	Each	150
356	denting and painting	per mtre	2500
357	Door lock new making	Each	200
358	Dynamo bearing	Each	150
	changing		
359	Electric welding	Each	150
	Engine head gasket	Each	2000
	changing		
361	Engine mount	Each	300
	changing		
362	Engine oil changing	Each	150
363	Engine Twining	Each	450

364	Engine water pump	Each	650
304	Engine water pump	Lacii	030
	changing		
365	Fan belt bearing	Each	250
	changing		
366	Fan belt changing	Each	150
367	Feed pump assy	Each	150
	1 .		
260	changing	F 1	150
	Feed pump repairing	Each	150
	Fly wheel changing	Each Each	2000 2000
	Fly wheel changing Fly wheel poolishing	Each	2000 850
	fuel and water	each	100
312		each	100
	separator cchanging		
	Fuel filter changing	Each	150
374	Fuel injection pump	Each	1500
255	opening & fitting	7. 1	***
375	Fuel over flow pipe	Each	200
	changing		
376	fuel pipe changing	each	250
377	Fuel tank opening &	Each	750
	fitting		
378	Fuel tank servicing	Each	350
379	Full Engine	Each	8500
	Osserik saaliise s		
200	Overhauling Gear oil changing	Each	150
		Each	250
	Gear shaft changing Gear shaft polishing	Each	250
	Half Engine	Each	3500
363	-	Lacii	3300
	Overhauling		
384	Head light assy	Each	200
	changing		
385	Head light bulb fitting	Each	120
386	horn and switch fitting	per set	250
387	Horn fitting	Each	250
388	Horn relay fitting	Each	150
389	Hub greasing (Fr)	Each	250
390	Hub greasing (Rear)	Each	250
391	hubs bearing changing	per piece	150
392	Hydraulic control valve opening	Each	10
	servicing & refitting		
393	Hydraulic filter	Each	10
	l	I	

	changing	I	
394	Hydraulic hose pipe	Each	10
	changing		
395	Hydraulic oil changing	Each	10
	Hydraulic pipe	Each	10
370		Lucii	10
	changing		
397	Hydraulic pipe leakage	Each	10
	repairing		
398	Hydraulic pump &	Each	10
	pipe line new fitting		
399	Hydraulic tank	Each	10
	servicing		
400	Ignition switch	Each	350
	changing		
401	Inner wheel bearing	Each	250
101		24011	230
	changing (Fr)		
402	Inner wheel bearing	Each	250
402	changing (Rear)	F 1	100
403	Inner wheel bearing	Each	100
404	oil seal changing (Fr) Inner wheel bearing oil seal changing	Each	100
404	(Rear)	Lacii	100
405	King pin bush machinery cutting	Each	200
.02	botrh side		
406	King pin overhauling	Each	200
	bothside		
407	KM cable changing &	Each	150
407	Kivi caole changing &	Lacii	150
	refitting		
408	Lower clutch kit	Each	250
	changing		
409	Lower Radiator hose	Each	150
	pipe changing		
410	Master cylinder	Each	350
	-		
411	changing Master cylinder kit	Each	350
411	-	Edell	330
	changing		
412	Master cylinder	Each	350
	repairing		
413	mobile filter changing	Each	100
414	Number Plate change	Each	100

415	Outer wheel bearing	Each	200
413	Outer wheel bearing	Each	200
	changing (Fr)		
416	Outer wheel bearing	Each	200
	changing (Rear)		
417	Outer wheel bearing	Each	100
	oil seal changing (Fr)		
418	Outer wheel bearing	Each	100
	oil seal changing (Rear)		
419	Power steering	Each	1500
	overhauling		
420	Power steering pump	Each	450
	change		
421	Pressure plate	Each	1500
	-		
	changing		
422	Pressure water pump	Each	650
	removal, refitting and gasket changing		
423	Propeller shaft york	Each	350
	changing		
424	PTO bracket new	Each	10
	making		
425	PTO bracket removal	Each	10
426	PTO pump servicing	Each	10
427	Quarter pin changing	Each	10
428	Radiator assy changing	Each	450
429	Radiator repairing &	Each	2200
120	servicing	F 1	100
	Rain guard fitting	Each	100
431	Rear bumpeer open	Each	250
122	fitting and welding	г 1	10
432	Rear hydraulic jack opening & new seal kit	Eacn	10
	fitting		
433	recovery van hiring	Per Km	500
	charges		
434	Release bearing	Each	250
.5 1	-		
	changing		
435	Release bearing fork	Each	250
	changing		
436	Release bearing lock	Each	250
	changing		
437	Seal kit changing	Each	100
	Seat new making	Set	3500
	Ü		

439	Self Bush changing	Each	100
440	Self carbon changing	Each	100
441	Self Overhauling	Each	650
442	Self rewinding	Each	350
443	Shock absorber	Each	150
	changing		
444	Side door glass	Each	250
	-	Edeli	230
	changing		
445	Solonoid switch	Each	150
	changing		
446	Spring buffer	Each	250
	mounting changing		
447	Spring bush changing	Each	250
	spring clam welding	per piece	100
449	Spring clam changing	Each	250
450	Spring hanger	Each	250
	changing		
451	Spring pin bush	Each	200
731	Spring pin ousii	Lacii	200
	changing		
452	Spring Shackle pin	Each	150
	changing		
453	Steering box kit	Each	750
	changing		
454	Steering box oil seal	Each	250
	-		
	changing		
455	Steering box	Each	1250
	overhauling		
456	Steering Column	Each	100
	changing (inner)		
457	Steering Column	Each	100
	changing (Outer)		
458	Steering cross bearing	Each	750
	changing		
459	Steering cross	Each	150
	changing		
460	Steering rack changing	Each	1250
	Steering rack changing Steering wheel	Each	150
701	opening & refitting	134011	130
462	Tail pinion oil seal	Each	450
.02	-		
	change		

463	Tailgate Repairing	Each	500
	Tappet adjusting	Each	350
	Tie rod end changing	Each	350
	Tie rod kit changing	Each	10
	Timing belt changing	Each	10
	Timing cover gear	Each	250
700	Timing cover gear	Lacii	250
	changing		
469	Transmission half	Each	1500
	overhauling		
470	Transmission over	Each	4500
	hauling		
	U bolt changing	Each	250
472	Upper clutch kit	Each	450
	changing		
473	Upper Radiator hose	Each	200
	alas atrausius		
474	pipe changing Vaccum pipe changing	Each	10
			10
4/5	vacuum nozzle pipe	each	10
	changing		
476	Vacuum pipe socket	Each	10
	changing		
477	Valve O ring changing	Each	10
	Valve oil seal changing	Each	10
	Valve spring changing	Each	10
	Water filter changing	Each	100
	Water level indicator	Each	10
	pipe changing		
482	Water pump assy	Each	100
	servicing		
483	Water separator	Each	150
40.4	changing	72.4	100
484	Water separator	Each	100
	servicing		
485	Wind shield replacing	Each	1500
486	Wiper arm changing	Each	100
487	Wiper blade changing	Each	100
488	Wiper motor changing	Each	250
489	Wiper motor repairing	Each	750
_			