

Sl No	Description of Item (2)	Unit of Measurement (3)	Amount per line item
			<b>PEMA KHANGSAR MOTOR WORKS</b>
1	AC	Each	35000
2	A/C filter	per piece	650
3	Alternator Assy	Each	9500
4	Alternator carbon bush	Each	250
5	Alternator cut out	Each	650
6	Anabond paste (Big)	Each	120
7	Anabond paste (Small)	60 per packet	60
8	Back bumper	Each	2800
9	Back light Assy (Left)	Each	475
10	Back light Assy (Right)	Each	475
11	Battery cable +ive	Each	350
12	Battery cable -ive	Each	350
13	Bendix pinion	Each	850
14	Black tape	per piece	25
15	Brake light switch	Each	250
16	Bulb 1141	Each	20
17	Bulb 67	Each	20
18	bush stabilizer	150 per piece	150
19	Carbon bush 12 v	Each	200
20	Carbon holder	Each	250
21	Carbon rocker 12v	Each	950
22	cloth piece	10 per piece	10
23	collant	per litre	295
24	dash board polish	per piece	250
25	Dial wrench (6-32mm)	Set	1250
26	distilled water	per litre	25
27	Dust guard back and front	Set	950
28	Dynamo bearing	Each	250
29	Dynamo rocker	Each	950
30	Electric horn 2v	Each	450
31	foot mat	Set	1250
32	Front bumper	Each	2975
33	fuel and water separator	per piece	100
34	fuel pipe	per piece	50
35	Fuse 10 Amp	Each	15
36	Fuse 15 Amp	Each	15
37	Fuse 20 Amp	Each	15
38	Fuse 25 Amp	Each	15

39	Fuse 30 Amp	Each	25
40	Fuse 5 Amp	Each	15
41	Glow plug	Each	5
42	Grease	275 per kg	280
43	Grease gun	Each	1050
44	Head light Assy (Left)	Each	2450
45	Head light Assy (Right)	Each	2450
46	Head light bulb (Halogen)	Each	150
47	Horn high	Each	650
48	Horn low	Each	450
49	Horn relay	Each	250
50	horn switch	per piece	150
51	Hour meter	Each	5
52	Ignition switch	Each	950
53	LT wire 5mm	Each	25
54	LT wire 6mm	Each	25
55	LT wire 8mm	Each	45
56	Mobil (15w40)	per litre	425
57	nozzle pipe	per piece	225
58	Plastic lock	Each	10
59	Plastic tape	Each	20
60	PVC tape	Each	25
61	Rain guard	Set	1850
62	Rear tail board railing	Each	2800
63	Rectifier	Each	450
64	Red paper	Each	25
65	Relay 2 pin 12v	Each	150
66	Relay 3 pin 12v	Each	150
67	Relay 4 pin 12v	Each	200
68	Relay 5 pin 12v	Each	200
69	Rotor coil	Each	350
70	seat cover	Set	6500
71	Self Armerture 12v	Each	1850
72	Self bush 12V	Each	75
73	Self carbon 12V	Each	250
74	Self field coil 12v	Each	450
75	Self housing	Each	550
76	Self top cover	Each	150
77	Solonoid switch 12v	Each	1250
78	Speedo meter Assy	Each	2850
79	Speedo meter cable	Each	650
80	Speedo meter pinion	Each	100
81	Starter coil	Each	350
82	Starter relay 12v	Each	200
83	steering cover	per piece	550

84	Threading tape	Each	20
85	vacuum nozzle pipe	per piece	5
86	vehicle no. plate	450 per plate	500
87	wheel Drum	Each	2200
88	Wiper blade Assy	Each	250
89	Wiper motor	Each	1850
90	Wiring clip	Each	5
91	Bearing 6202	Each	250
92	Bearing 6302	Each	250
93	Benjo washer	Each	5
94	Cam shaft	Each	2200
95	Cam shaft bush	Each	650
96	Cam shaft gear	Each	450
97	Connecting bearing	Each	1250
98	Connecting bush	Each	450
99	Coonecting rod	Each	1250
100	Crank shaft	Each	12850
101	Crank shaft oil seal	Each	950
102	Diesel filter	Each	200
103	Drain plug	Each	50
104	Element Assy, Fuel	Each	1850
105	Element sub assy, Air	Each	650
106	Engine head gasket	Each	1250
107	Engine mounting	Each	350
108	Engine pacing	Each	100
109	Engine ring	Each	1950
110	Fan belt	Each	350
111	Feed pump Assy	Each	1850
112	Fuel filter	Each	200
113	Fuel injection overflow pipe	Each	250
114	Fuel injector nozzel	Each	1200
115	Fuel injector pipe	Each	250
116	Fuel pump Assy	Each	48000
117	Fuel pump washer	Each	10
118	Gas kit	Each	25
119	Hydraulic jack (Heavy Duty)	Each	3500
120	Hydraulic jack (Light Duty)	Each	2500
121	Hydraulic jack oil seal (Set of 12 pcs)	Each	250
122	Inner door lock (R )	Each	250
123	Inner door lock(L)	Each	250
124	Jack lever	Each	300
125	Main bearing	Each	1450
126	Mobil	per litre	395
127	Mobile filter	1050	250

128	Open end wrench set (6- 32mm)	Set	1500
129	Piston	Each	2850
130	Piston ring	Each	1850
131	Rocker Arm	Each	350
132	Rocker shaft	Each	200
133	Silencer box	Each	2500
134	Silencer pipe	Each	1250
135	Socket (6mm-32mm)	Set	4800
136	Tappid cover packing	Each	100
137	Thrust washer	Each	150
138	Timing cover oil seal	Each	200
139	Timing belt	Each	5
140	Timing cover	Each	100
141	Timing cover gear	Each	100
142	Valve guide	Each	250
143	Valve key	Each	10
144	Valve seal	Each	250
145	Valve spring	Each	50
146	Valve washer	Each	15
147	Wheel wrench	Each	350
148	Wiper Arm	Each	250
149	Wiper blade	Each	250
150	Wiper motor Assy	Each	2100
151	Axel lock	Each	25
152	Axel shaft	Each	3500
153	Axel shaft oil seal	Each	200
154	Axel spacer	Each	250
155	Back gear bearing	Each	450
156	ball joint	per piece	850
157	C.V joint	per piece	3500
158	Center bearing	Each	1300
159	Clutch cylinder (lower)	Each	1250
160	Clutch cylinder (Upper)	Each	1500
161	Clutch cylinder Assy	Each	1250
162	Clutch cylinder kit	Each	250
163	Clutch kit	Each	250
164	Clutch kit box	Each	250
165	Clutch plate (Fan Type)	Each	1500
166	Clutch plate (Round Type)	Each	4600
167	Clutch relese bearing	Each	950
168	Clutch rod	Each	100
169	Cross bearing	Each	650
170	Cross holder	Each	1250
171	Cross propeller shaft	Each	650
172	Crown tail assy	Each	6500

173	Fly wheel	Each	2000
174	Fly wheel ring	Each	450
175	Front hub bearing inner	Each	750
176	Front hub bearing outer	Each	750
177	Gear box mounting	Each	550
178	Gear box oil seal	Each	200
179	Gear box packing	Each	150
180	Gear counter	Each	3800
181	Gear oil	per litre	350
182	Gear pinion	Each	2200
183	Gear pinion shaft	Each	2500
184	Hubs bearing	per piece	750
185	Hubs checknut	Each	100
186	Hubs checknut lock	Each	75
187	Master cylinder	Each	3850
188	Master cylinder kit	Each	750
189	Pilot bearing	Each	450
190	Pressure plate	Each	2850
191	Propeller shaft	Each	3800
192	Propeller shaft bolt	Each	25
193	Rear hub bearing inner	Each	750
194	Rear hub bearing outer	Each	750
195	Relese bearing fork	Each	250
196	Relese bearing lock	Each	50
197	Tail pinion bearing (inner)	Each	1150
198	Tail pinion bearing (Outer)	Each	1150
199	Tail pinion chechnut washer	Each	75
200	Tail pinion checknut	Each	100
201	Tail Pinion oil seal	piece	200
202	Top shaft bearing	Each	650
203	Wheel bearing inner (Rear)	Each	750
204	Wheel bearing oil seal inner (Front)	Each	200
205	Wheel bearing oil seal inner (Rear)	Each	200
206	Wheel bearing outer (Front)	Each	750
207	Wheel bearing outer (Rear)	Each	750
208	Wheel cylinder	Each	875
209	Wheel cylinder bucket	Each	200
210	Wheel nut	Each	100
211	Accelerator cable	Each	325
212	Brake Booster Assy	Each	6800
213	Brake Booster kit	Each	450
214	Brake cam	Each	5
215	Brake cam Arm	Each	5
216	Brake cam Arm lock	Each	5

217	Brake cam bush	Each	5
218	brake disc	Each	1850
219	Brake flexible pipe (Front)	Each	350
220	Brake fluid dot3	Each	250
221	brake light bulb	per piece	20
222	Brake lining	Each	750
223	Brake oil	per litres	250
224	Brake pad	Each	1050
225	Brake pipe (Rear)	Each	300
226	Brake servo	Each	5
227	Brake shoe	Each	750
228	Brake shoe lock with spring	Each	300
229	Break bucket	Each	200
230	Break lining back and front	Each	750
231	Break shoe	Each	750
232	Controlling cylinder Assy	Each	5
233	Controlling pipe	Each	5
234	Controlling switch Assy	Each	5
235	Dual brake valve Assy	Each	5
236	Hand brake cable	Each	750
237	Oil seal	Each	100
238	Spring 2nd leaf (R)	Each	1150
239	Spring 2nd leaf (F)	Each	750
240	Spring 3rd leaf ®	Each	850
241	Spring 3rd leaf (F)	Each	650
242	Spring 4th leaf ®	Each	750
243	Spring 4th leaf (F)	Each	500
244	Spring 5th leaf ®	Each	500
245	Spring 5th leaf (F)	Each	400
246	Spring 6th leaf ®	Each	350
247	Spring 6th leaf (F)	Each	300
248	Centre bolt	Each	50
249	Cycle pin	Each	175
250	Helper leaf Spring	Each	750
251	Main leaf spring ( R)	Each	1150
252	Main leaf spring (F)	Each	850
253	Shock absorber	Each	1200
254	Shocker nut bolt	Each	50
255	Spring buffer mounting	Each	250
256	Spring bush	Each	100
257	Spring clamp	Each	150
258	Spring cycle pin	Each	150
259	Spring hanger	Each	650
260	Spring pin	Each	150
261	Spring shackle	Each	550

262	U bolt	Each	250
263	U bolt nut	Each	45
264	U bolt plate	Each	295
265	Air filter	Each	450
266	Air filter hose pipe	Each	250
267	Coolant	per litres	245
268	Exhaust manifold	Each	1950
269	Hose pipe clamp	Each	50
270	Hydraulic filter	Each	10
271	Hydraulic oil	per litre	200
272	Hydraulic pipe	Each	10
273	Intake manifold	Each	1200
274	Radiator assy	Each	4850
275	Radiator cap	Each	200
276	radiator hose pipe (Lower)	Each	300
277	Radiator hose pipe (Upper )	Each	300
278	Vacuum pipe	Each	10
279	Arm bushing lower big	Each	450
280	Arm bushing lower small	Each	450
281	Power steering box Assy	Each	16500
282	Steering adjuster bolt Assy	Each	100
283	Steering box oil seal	Each	100
284	Steering column (Inner)	Each	250
285	Steering column (Outer)	Each	250
286	Steering cross	Each	750
287	Steering cross bearing	Each	750
288	Tie rod end	Each	595
289	Back glass	Each	1500
290	Front Windshield glass	Each	4500
291	Looking glass ( R )	Each	250
292	Looking glass (L)	Each	250
293	Window glass	Each	1000
294	Power steering bearing	Each	250
295	Power steering oil	per litres	330
296	Power steering pipe	Each	200
297	Head light assembly	Each	2450
298	Head light bulb	Each	150
299	Head light cover	Each	250
300	Indicator light	Each	150
301	Side light	Each	10
302	Gear Box Opening and fitting charges	each	3500
303	Spring opening and fitting charges	each	350
304	A/c filter changing	per piece	100

305	Accelerator cable changing	Each	100
306	Air compressor leakage repairing	Each	10
307	Air Element changing	Each	100
308	Air filter changing	Each	100
309	Air filter hose pipe changing	Each	100
310	Air filter servicing	Each	100
311	Air tank opening & refitting	Each	10
312	Air unloader opening & new service kit fitting	Each	10
313	Alternator cut out changing	Each	450
314	Alternator overhauling	Each	450
315	Arm bush change charges	Each	450
316	Back light assy changing	Each	100
317	Back light bulb changing	Each	100
318	ball joint changing	per piece	450
319	Battery box new making	Each	350
320	Battery cable changing	Each	100
321	Battery change	Each	50
322	Battery terminal changing	Each	50
323	Bendix pinion repairing & replacing	Each	150
324	Brake adjuster opening & refitting	Each	10
325	Brake cam bush opening & fitting	Each	10
326	Brake diafam opening & new service kit changing	Each	10
327	Brake disc cutting	Each	650
328	brake disc changing	Each	350
329	Brake drum cutting	Each	500
330	Brake dual valve kit changing	Each	10
331	Brake flexible pipe changing	Each	100
332	Brake lining changing	Each	250
333	brake pipe bleasting	each	150
334	Brake pipe changing	Each	150
335	Brake pipe leakage repairing	Each	150
336	Brake servo Changing	Each	20
337	Brake servo repairing & servicing	Each	20
338	Brake Shoe Changing	Each	350
339	Brass blezzing	Each	150
340	Carbon soldering	Each	100

341	Center bearing changing	Each	350
342	Clutch plate changing	Each	2500
343	Clutch release bearing changing	Each	2500
344	Coil Spring changing	Each	250
345	collant change	Each	100
346	Controlling overhauling	Each	10
347	Controlling pipe changing	Each	10
348	Cross bearing changing	Each	350
349	Cross bearing greasing	Each	200
350	Cross Coupling cutting by lath machine	each	550
351	Cross holder cutting and welding	Each	550
352	Crown Overhauling	Each	2000
353	CV joint changing	per piece	250
354	Cycle pin changing	Each	150
355	denting and painting	per mtre	2500
356	Door lock new making	Each	200
357	Dynamo bearing changing	Each	150
358	Electric welding	Each	150
359	Engine head gasket changing	Each	2000
360	Engine mount changing	Each	300
361	Engine oil changing	Each	150
362	Engine Twining	Each	450
363	Engine water pump changing	Each	650
364	Fan belt bearing changing	Each	250
365	Fan belt changing	Each	150
366	Feed pump assy changing	Each	150
367	Feed pump repairing	Each	150
368	Fly wheel changing	Each	2000
369	Fly wheel changing	Each	2000
370	Fly wheel poolishing	Each	850
371	fuel and water separator cchanging	each	100
372	Fuel filter changing	Each	100

373	Fuel injection pump opening & fitting	Each	1500
374	Fuel over flow pipe changing	Each	200
375	fuel pipe changing	each	250
376	Fuel tank opening & fitting	Each	750
377	Fuel tank servicing	Each	350
378	Full Engine Overhauling	Each	8500
379	Gear oil changing	Each	150
380	Gear shaft changing	Each	250
381	Gear shaft polishing	Each	250
382	Half Engine Overhauling	Each	4200
383	Head light assy changing	Each	200
384	Head light bulb fitting	Each	120
385	horn and switch fitting	per set	250
386	Horn fitting	Each	250
387	Horn relay fitting	Each	150
388	Hub greasing (Fr)	Each	250
389	Hub greasing (Rear)	Each	250
390	hubs bearing changing	per piece	150
391	Hydraulic control valve opening servicing & refitting	Each	10
392	Hydraulic filter changing	Each	10
393	Hydraulic hose pipe changing	Each	10
394	Hydraulic oil changing	Each	10
395	Hydraulic pipe changing	Each	10
396	Hydraulic pipe leakage repairing	Each	10
397	Hydraulic pump & pipe line new fitting	Each	10
398	Hydraulic tank servicing	Each	10
399	Ignition switch changing	Each	350
400	Inner wheel bearing changing (Fr)	Each	250
401	Inner wheel bearing changing (Rear)	Each	250
402	Inner wheel bearing oil seal changing (Fr)	Each	100
403	Inner wheel bearing oil seal changing (Rear)	Each	100

404	King pin bush machinery cutting both side	Each	200
405	King pin overhauling bothside	Each	200
406	KM cable changing & refitting	Each	150
407	Lower clutch kit changing	Each	250
408	Lower Radiator hose pipe changing	Each	150
409	Master cylinder changing	Each	350
410	Master cylinder kit changing	Each	350
411	Master cylinder repairing	Each	350
412	mobile filter changing	Each	100
413	Number Plate change	Each	100
414	Outer wheel bearing changing (Fr)	Each	200
415	Outer wheel bearing changing (Rear)	Each	200
416	Outer wheel bearing oil seal changing (Fr)	Each	100
417	Outer wheel bearing oil seal changing (Rear)	Each	100
418	Power steering overhauling	Each	1500
419	Power steering pump change	Each	450
420	Pressure plate changing	Each	2000
421	Pressure water pump removal, refitting and gasket changing	Each	450
422	Propeller shaft yolk changing	Each	350
423	PTO bracket new making	Each	10
424	PTO bracket removal	Each	10
425	PTO pump servicing	Each	10
426	Quarter pin changing	Each	10
427	Radiator assy changing	Each	450

428	Radiator repairing & servicing	Each	2200
429	Rain guard fitting	Each	100
430	Rear bumper open fitting and welding	Each	250
431	Rear hydraulic jack opening & new seal kit fitting	Each	10
432	recovery van hiring charges	Per Km	2000
433	Release bearing changing	Each	250
434	Release bearing fork changing	Each	250
435	Release bearing lock changing	Each	250
436	Seal kit changing	Each	100
437	Seat new making	Set	5000
438	Self Bush changing	Each	100
439	Self carbon changing	Each	100
440	Self Overhauling	Each	450
441	Self rewinding	Each	975
442	Shock absorber changing	Each	150
443	Side door glass changing	Each	250
444	Solonoid switch changing	Each	250
445	Spring buffer mounting changing	Each	250
446	Spring bush changing	Each	150
447	spring clam welding	per piece	100
448	Spring clam changing	Each	150
449	Spring hanger changing	Each	200
450	Spring pin bush changing	Each	200
451	Spring Shackle pin changing	Each	150
452	Steering box kit changing	Each	750
453	Steering box oil seal changing	Each	250

454	Steering box overhauling	Each	1450
455	Steering Column changing (inner)	Each	100
456	Steering Column changing (Outer)	Each	100
457	Steering cross bearing changing	Each	350
458	Steering cross changing	Each	350
459	Steering rack changing	Each	1250
460	Steering wheel opening & refitting	Each	150
461	Tail pinion oil seal change	Each	250
462	Tailgate Repairing	Each	100
463	Tappet adjusting	Each	100
464	Tie rod end changing	Each	250
465	Tie rod kit changing	Each	150
466	Timing belt changing	Each	100
467	Timing cover gear changing	Each	500
468	Transmission half overhauling	Each	3000
469	Transmission over hauling	Each	4500
470	U bolt changing	Each	150
471	Upper clutch kit changing	Each	350
472	Upper Radiator hose pipe changing	Each	200
473	Vaccum pipe changing	Each	10
474	vacuum nozzle pipe changing	each	10
475	Vacuum pipe socket changing	Each	10
476	Valve O ring changing	Each	50
477	Valve oil seal changing	Each	250
478	Valve spring changing	Each	200
479	Water filter changing	Each	100
480	Water level indicator pipe changing	Each	10
481	Water pump assy servicing	Each	250
482	Water separator changing	Each	350
483	Water separator servicing	Each	100
484	Wind shield replacing	Each	1500

485	Wiper arm changing	Each	100
486	Wiper blade changing	Each	100
487	Wiper motor changing	Each	250
488	Wiper motor repairing	Each	750