

SI No	Description of Item (2)	Unit of Measurement (3)	Amount per line item
			PEMA KHANGSAR MOTOR WORKS
1	Battery terminal end	Each	100
2	A/C filter	per piece	1650
3	Alternator Assy	Each	18000
4	Alternator carbon bush	Each	200
5	Alternator cut out	Each	3200
6	Anabond paste (Big)	Each	125
7	Anabond paste (Small)	Each	65
8	Back bumper	Each	18500
9	Back light Assy (Left)	Each	3500
10	Back light Assy (Right)	Each	3500
11	Battery cable +ive	Each	250
12	Battery cable -ive	Each	250
13	Bendix pinion	Each	2850
14	Black tape	per piece	25
15	Brake light switch	Each	250
16	Bulb 1141	Each	25
17	Bulb 67	Each	25
18	bush stabilzer	per piece	475
19	Carbon bush 12 v	Each	150
20	Carbon holder	Each	150
21	Carbon rocker 12v	Each	1850
22	cloth piece	per meter	10
23	collant	per ltre	285
24	dash board polish	per piece	250
25	Dial wrench (6-32mm)	Set	1050
26	distilled water	per ltre	25
27	Dust guard back and front	Set	2850
28	Dynamo bearing	Each	250
29	Dynamo rocker	Each	250
30	Electric horn 2v	Each	450
31	foot mat	Set	2850
32	Front bumper	Each	18500
33	fuel and water separator	per piece	950
34	fuel pipe	per piece	250
35	Fuse 10 Amp	Each	10
36	Fuse 15 Amp	Each	10
37	Fuse 20 Amp	Each	10
38	Fuse 25 Amp	Each	15
39	Fuse 30 Amp	Each	25
40	Fuse 5 Amp	Each	10

41	Glow plug	Each	950
42	Grease	per kg	250
43	Grease gun	Each	1050
44	Head light Assy (Left)	Each	14500
45	Head light Assy (Right)	Each	14500
46	Head light bulb (Halogen)	Each	150
47	Horn high	Each	650
48	Horn low	Each	450
49	Horn relay	Each	250
50	horn switch	per piece	200
51	Hour meter	Each	10
52	Ignition switch	Each	2850
53	LT wire 5mm	Each	25
54	LT wire 6mm	Each	25
55	LT wire 8mm	Each	50
56	Mobil (15w40)	per litre	425
57	nozzle pipe	per piece	250
58	Plastic lock	Each	10
59	Plastic tape	Each	25
60	PVC tape	Each	25
61	Rain guard	Set	2500
62	Rear tail board railing	Each	10
63	Rectifier	Each	1200
64	Red paper	Each	25
65	Relay 2 pin 12v	Each	150
66	Relay 3 pin 12v	Each	150
67	Relay 4 pin 12v	Each	200
68	Relay 5 pin 12v	Each	200
69	Rotor coil	Each	350
70	seat cover	Set	6500
71	Self Armerture 12v	Each	4500
72	Self bush 12V	Each	50
73	Self carbon 12V	Each	200
74	Self field coil 12v	Each	450
75	Self housing	Each	1250
76	Self top cover	Each	250
77	Solonoid switch 12v	Each	2850
78	Speedo meter Assy	Each	3250
79	Speedo meter cable	Each	250
80	Speedo meter pinion	Each	100
81	Starter coil	Each	450
82	Starter relay 12v	Each	250
83	steering cover	per piece	550
84	Threading tape	Each	25
85	vacuum nozzle pipe	per piece	10

86	vehicle no. plate	per piece	10
87	wheel Drum	Each	8500
88	Wiper blade Assy	Each	350
89	Wiper motor	Each	5000
90	Wiring clip	Each	5
91	Bearing 6202	Each	200
92	Bearing 6302	Each	200
93	Benjo washer	Each	5
94	Cam shaft	Each	2500
95	Cam shaft bush	Each	250
96	Cam shaft gear	Each	250
97	Connecting bearing	Each	1850
98	Connecting bush	Each	750
99	Coonecting rod	Each	4200
100	Crank shaft	Each	25000
101	Crank shaft oil seal	Each	1250
102	Diesel filter	Nos	950
103	Drain plug	Each	100
104	Element Assy, Fuel	Each	1500
105	Element sub assy, Air	Each	2100
106	Engine head gasket	Each	4200
107	Engine mounting	Each	1200
108	Engine pacing	Each	100
109	Engine ring	Each	100
110	Fan belt	Each	1500
111	Feed pump Assy	Each	2200
112	Fuel filter	Each	950
113	Fuel injection overflow pipe	Each	750
114	Fuel injector nozzel	Each	1450
115	Fuel injector pipe	Each	250
116	Fuel pump Assy	Each	105000
117	Fuel pump washer	Each	50
118	Gas kit	Each	100
119	Hydraulic jack (Heavy Duty)	Each	2850
120	Hydraulic jack (Light Duty)	Each	2500
121	Hydraulic jack oil seal (Set of 12 pcs)	Each	150
122	Inner door lock (R)	Each	1450
123	Inner door lock(L)	Each	1450
124	Jack lever	Each	950
125	Main bearing	Each	2200
126	Mobile	per litre	425
127	Mobile filter	Each	950
128	Open end wrench set (6- 32mm)	Set	1275
129	Piston	Each	3250
130	Piston ring	Each	6500

131	Rocker Arm	Each	150
132	Rocker shaft	Each	150
133	Silencer box	Each	3850
134	Silencer pipe	Each	2500
135	Socket (6mm-32mm)	Set	4850
136	Tappid cover packing	Each	250
137	Thrust washer	Each	275
138	Timing cover oil seal	Each	650
139	Timing belt	Each	3500
140	Timing cover	Each	250
141	Timing cover gear	Each	750
142	Valve guide	Each	950
143	Valve key	Each	10
144	Valve seal	Each	350
145	Valve spring	Each	250
146	Valve washer	Each	50
147	Wheel wrench	Each	975
148	Wiper Arm	Each	750
149	Wiper blade	Each	350
150	Wiper motor Assy	Each	3250
151	Axel lock	Each	200
152	Axel shaft	Each	12800
153	Axel shaft oil seal	Each	750
154	Axel spacer	Each	250
155	Back gear bearing	Each	250
156	ball joint	per piece	10
157	C.V joint	per piece	100
158	Center bearing	Each	10
159	Clutch cylinder (lower)	Each	2200
160	Clutch cylinder (Upper)	Each	2950
161	Clutch cylinder Assy	Each	675
162	Clutch cylinder kit	Each	675
163	Clutch kit	Each	250
164	Clutch kit box	Each	250
165	Clutch plate (Fan Type)	Each	5
166	Clutch plate (Round Type)	Each	6500
167	Clutch relese bearing	Each	4500
168	Clutch rod	Each	10
169	Cross bearing	Each	2200
170	Cross holder	Each	3250
171	Cross propeller shaft	Each	2200
172	Crown tail assy	Each	60000
173	Fly wheel	Each	3500
174	Fly wheel ring	Each	1500
175	Front hub bearing inner	Each	1450

176	Front hub bearing outer	Each	1250
177	Gear box mounting	Each	2200
178	Gear box oil seal	Each	950
179	Gear box packing	Each	250
180	Gear counter	Each	2800
181	Gear oil	per litre	385
182	Gear pinion	Each	1500
183	Gear pinion shaft	Each	500
184	Hubs bearing	per piece	1250
185	Hubs checknut	Each	150
186	Hubs checknut lock	Each	100
187	Master cylinder	Each	6850
188	Master cylinder kit	Each	1250
189	Pilot bearing	Each	850
190	Pressure plate	Each	6500
191	Propeller shaft	Each	12500
192	Propeller shaft bolt	Each	65
193	Rear hub bearing inner	Each	1450
194	Rear hub bearing outer	Each	1250
195	Relese bearing fork	Each	250
196	Relese bearing lock	Each	100
197	Tail pinion bearing (inner)	Each	3875
198	Tail pinion bearing (Outer)	Each	3875
199	Tail pinion chechnut washer	Each	100
200	Tail pinion checknut	Each	250
201	Tail Pinion oil seal	piece	850
202	Top shaft bearing	Each	1500
203	Wheel bearing inner (Front)	Each	1450
204	Wheel bearing inner (Rear)	Each	1450
205	Wheel bearing oil seal inner (Front)	Each	750
206	Wheel bearing oil seal inner (Rear)	Each	750
207	Wheel bearing outer (Front)	Each	1250
208	Wheel bearing outer (Rear)	Each	1250
209	Wheel cylinder	Each	2500
210	Wheel cylinder bucket	Each	350
211	Wheel nut	Each	250
212	Accelerator cable	Each	1250
213	Brake Booster Assy	Each	15500
214	Brake Booster kit	Each	1500
215	Brake cam	Each	5
216	Brake cam Arm	Each	5
217	Brake cam Arm lock	Each	5
218	Brake cam bush	Each	5
219	brake disc	Each	6850
220	Brake flexible pipe (Front)	Each	450

221	Brake fluid dot3	Each	450
222	brake light bulb	per piece	25
223	Brake lining	Each	5500
224	Brake oil	per litres	450
225	Brake pad	Each	5500
226	Brake pipe (Rear)	Each	250
227	Brake servo	Each	5
228	Brake shoe	Each	5500
229	Brake shoe lock with spring	Each	500
230	Break bucket	Each	500
231	Break lining back and front	Each	5500
232	Break shoe	Each	5500
233	Controlling cylinder Assy	Each	5
234	Controlling pipe	Each	5
235	Controlling switch Assy	Each	5
236	Dual brake valve Assy	Each	5
237	Hand brake cable	Each	3500
238	Oil seal	Each	250
239	Spring 2nd leaf (R)	Each	4500
240	Spring 2nd leaf (F)	Each	5
241	Spring 3rd leaf ®	Each	1850
242	Spring 3rd leaf (F)	Each	5
243	Spring 4th leaf ®	Each	1500
244	Spring 4th leaf (F)	Each	5
245	Spring 5th leaf ®	Each	1200
246	Spring 5th leaf (F)	Each	5
247	Spring 6th leaf ®	Each	850
248	Spring 6th leaf (F)	Each	5
249	Centre bolt	Each	150
250	Cycle pin	Each	750
251	Helper leaf Spring	Each	1500
252	Main leaf spring (R)	Each	1500
253	Main leaf spring (F)	Each	5
254	Shock absorber	Each	6800
255	Shocker nut bolt	Each	100
256	Spring buffer mounting	Each	975
257	Spring bush	Each	200
258	Spring clamp	Each	200
259	Spring cycle pin	Each	950
260	Spring hanger	Each	1500
261	Spring pin	Each	950
262	Spring shackle	Each	1500
263	U bolt	Each	500
264	U bolt nut	Each	100
265	U bolt plate	Each	450

266	Air filter	Each	2200
267	Air filter hose pipe	Each	450
268	Coolant	per litres	285
269	Exhaust manifold	Each	1850
270	Hose pipe clamp	Each	150
271	Hydraulic filter	Each	5
272	Hydraulic oil	per litre	250
273	Hydraulic pipe	Each	5
274	Intake manifold	Each	1250
275	Radiator assy	Each	26000
276	Radiator cap	Each	250
277	radiator hose pipe (Lower)	Each	350
278	Radiator hose pipe (Upper)	Each	350
279	Vacuum pipe	Each	5
280	Arm bushing lower big	Each	1650
281	Arm bushing lower small	Each	1450
282	Power steering box Assy	Each	68000
283	Steering adjuster bolt Assy	Each	100
284	Steering box oil seal	Each	100
285	Steering column (Inner)	Each	250
286	Steering column (Outer)	Each	250
287	Steering cross	Each	2850
288	Steering cross bearing	Each	2850
289	Tie rod end	Each	2450
290	Back glass	Each	4800
291	Front Windshield glass	Each	18500
292	Looking glass (R)	Each	3850
293	Looking glass (L)	Each	3850
294	Window glass	Each	4850
295	Power steering bearing	Each	250
296	Power steering oil	per litres	250
297	Power steering pipe	Each	350
298	Head light assembly	Each	16500
299	Head light bulb	Each	150
300	Head light cover	Each	5
301	Indicator light	Each	5
302	Side light	Each	5
303	Gear Box Opening and fitting charges	each	6500
304	Spring opening and fitting charges	each	650
305	A/c filter changing	per piece	100
306	Accelerator cable changing	Each	250
307	Air compressor leakage repairing	Each	5
308	Air Element changing	Each	100
309	Air filter changing	Each	100

310	Air filter hose pipe changing	Each	100
311	Air filter servicing	Each	150
312	Air tank opening & refitting	Each	5
313	Air unloader opening & new service kit fitting	Each	5
314	Alternator cut out changing	Each	150
315	Alternator overhauling	Each	850
316	Arm bush change charges	Each	650
317	Back light assy changing	Each	200
318	Back light bulb changing	Each	200
319	ball joint changing	per piece	5
320	Battery box new making	Each	400
321	Battery cable changing	Each	150
322	Battery change	Each	100
323	Battery terminal changing	Each	100
324	Bendix pinion repairing & replacing	Each	350
325	Brake adjuster opening & refitting	Each	5
326	Brake cam bush opening & fitting	Each	5
327	Brake diafam opening & new service kit changing	Each	5
328	Brake dise cutting	Each	650
329	brake disc changing	Each	450
330	Brake drum cutting	Each	650
331	Brake dual valve kit changing	Each	5
332	Brake flexible pipe changing	Each	200
333	Brake linning changing	Each	450
334	brake pipe bleasting	each	250
335	Brake pipe changing	Each	250
336	Brake pipe leakage repairing	Each	250
337	Brake servo Changing	Each	5
338	Brake servo repairing & servicing	Each	5
339	Brake Shoe Changing	Each	450
340	Brass blezzing	Each	250
341	Carbon soldering	Each	200
342	Center bearing changing	Each	10
343	Clutch plate changing	Each	4500
344	Clutch release bearing changing	Each	1500
345	Coil Spring changing	Each	650
346	collant change	Each	150
347	Controlling overhauling	Each	5
348	Controlling pipe changing	Each	5
349	Cross bearing changing	Each	450
350	Cross bearing greasing	Each	450
351	Cross Coupling cutting by lath machine	each	950
352	Cross holder cutting and welding	Each	950
353	Crown Overhauling	Each	2500

354	CV joint changing	per piece	350
355	Cycle pin changing	Each	350
356	denting and painting	per mtr	4500
357	Door lock new making	Each	450
358	Dynamo bearing changing	Each	250
359	Electric welding	Each	350
360	Engine head gasket changing	Each	2500
361	Engine mount changing	Each	450
362	Engine oil changing	Each	250
363	Engine Twining	Each	650
364	Engine water pump changing	Each	650
365	Fan belt bearing changing	Each	450
366	Fan belt changing	Each	350
367	Feed pump assy changing	Each	250
368	Feed pump repairing	Each	100
369	Fly wheel changing	Each	1500
370	Fly wheel changing	Each	1500
371	Fly wheel poolishing	Each	1200
372	fuel and water separator cchanging	each	100
373	Fuel filter changing	Each	200
374	Fuel injection pump opening & fitting	Each	1200
375	Fuel over flow pipe changing	Each	250
376	fuel pipe changing	each	150
377	Fuel tank opening & fitting	Each	850
378	Fuel tank servicing	Each	950
379	Full Engine Overhauling	Each	8500
380	Gear oil changing	Each	350
381	Gear shaft changing	Each	250
382	Gear shaft polishing	Each	150
383	Half Engine Overhauling	Each	3500
384	Head light assy changing	Each	350
385	Head light bulb fitting	Each	200
386	horn and switch fitting	per set	250
387	Horn fitting	Each	250
388	Horn relay fitting	Each	100
389	Hub greasing (Fr)	Each	450
390	Hub greasing (Rear)	Each	450
391	hubs bearing changing	per piece	150
392	Hydraulic control valve opening servicing & refitting	Each	5
393	Hydraulic filter changing	Each	5
394	Hydraulic hose pipe changing	Each	5
395	Hydraulic oil changing	Each	5
396	Hydraulic pipe changing	Each	5
397	Hydraulic pipe leakage repairing	Each	5

398	Hydraulic pump & pipe line new fitting	Each	5
399	Hydraulic tank servicing	Each	5
400	Ignition switch changing	Each	650
401	Inner wheel bearing changing (Fr)	Each	150
402	Inner wheel bearing changing (Rear)	Each	150
403	Inner wheel bearing oil seal changing (Fr)	Each	150
404	Inner wheel bearing oil seal changing (Rear)	Each	150
405	King pin bush machinery cutting both side	Each	400
406	King pin overhauling bothside	Each	650
407	KM cable changing & refitting	Each	250
408	Lower clutch kit changing	Each	350
409	Lower Radiator hose pipe changing	Each	250
410	Master cylinder changing	Each	450
411	Master cylinder kit changing	Each	450
412	Master cylinder repairing	Each	450
413	mobile filter changing	Each	100
414	Number Plate change	Each	100
415	Outer wheel bearing changing (Fr)	Each	150
416	Outer wheel bearing changing (Rear)	Each	150
417	Outer wheel bearing oil seal changing (Fr)	Each	150
418	Outer wheel bearing oil seal changing (Rear)	Each	150
419	Power steering overhauling	Each	2500
420	Power steering pump change	Each	850
421	Pressure plate changing	Each	2500
422	Pressure water pump removal, refitting and gasket changing	Each	150
423	Propeller shaft york changing	Each	450
424	PTO bracket new making	Each	5
425	PTO bracket removal	Each	5
426	PTO pump servicing	Each	5
427	Quarter pin changing	Each	5
428	Radiator assy changing	Each	650
429	Radiator repairing & servicing	Each	3500
430	Rain guard fitting	Each	100
431	Rear bumper open fitting and welding	Each	650
432	Rear hydraulic jack opening & new seal kit fitting	Each	5
433	recovery van hiring charges	Per Km	2500
434	Release bearing changing	Each	1500
435	Release bearing fork changing	Each	250
436	Release bearing lock changing	Each	250
437	Seal kit changing	Each	100
438	Seat new making	Set	4500

439	Self Bush changing	Each	150
440	Self carbon changing	Each	150
441	Self Overhauling	Each	850
442	Self rewinding	Each	250
443	Shock absorber changing	Each	150
444	Side door glass changing	Each	450
445	Soloid switch changing	Each	150
446	Spring buffer mounting changing	Each	250
447	Spring bush changing	Each	350
448	spring clam welding	per piece	150
449	Spring clam changing	Each	250
450	Spring hanger changing	Each	450
451	Spring pin bush changing	Each	350
452	Spring Shackle pin changing	Each	150
453	Steering box kit changing	Each	250
454	Steering box oil seal changing	Each	250
455	Steering box overhauling	Each	2500
456	Steering Column changing (inner)	Each	100
457	Steering Column changing (Outer)	Each	100
458	Steering cross bearing changing	Each	350
459	Steering cross changing	Each	350
460	Steering rack changing	Each	5
461	Steering wheel opening & refitting	Each	250
462	Tail pinion oil seal change	Each	450
463	Tailgate Repairing	Each	5
464	Tappet adjusting	Each	250
465	Tie rod end changing	Each	350
466	Tie rod kit changing	Each	5
467	Timing belt changing	Each	1250
468	Timing cover gear changing	Each	250
469	Transmission half overhauling	Each	3500
470	Transmission over hauling	Each	6500
471	U bolt changing	Each	250
472	Upper clutch kit changing	Each	350
473	Upper Radiator hose pipe changing	Each	200
474	Vaccum pipe changing	Each	5
475	vacuum nozzle pipe changing	each	5
476	Vacuum pipe socket changing	Each	5
477	Valve O ring changing	Each	10
478	Valve oil seal changing	Each	10
479	Valve spring changing	Each	10
480	Water filter changing	Each	100
481	Water level indicator pipe changing	Each	20
482	Water pump assy servicing	Each	650
483	Water separator changing	Each	50

484	Water separator servicing	Each	250
485	Wind shield replacing	Each	2500
486	Wiper arm changing	Each	100
487	Wiper blade changing	Each	100
488	Wiper motor changing	Each	650
489	Wiper motor repairing	Each	1500
490	Siren assemble	Each	3500
491	niple greasing	service	450
492	water servicing	service	500
493	tyre changing	service	150
494	break servicing	service	350
495	sprin bush	per piece	225
496	D-bush	per piece	875
497	shocker bush	per piece	250
498	check nut	per piece	150
499	brake plate	set	650
500	brake shoos	set	5500
501	hub bearing	per piece	1250
502	inner bearing	per piece	1450
503	outer bearing	per piece	1250
504	engine oil	per ltrs	425
505	disel filter	per piece	950
506	coolant	per ltrs	285
507	Gear oil	per ltrs	350
508	Timing belt changing	per piece	1200
509	kin-pin bearing	per piece	950
510	nut bolt	per piece	45
